

IN4181 - Wireless Sensor Networks

Koen Langendoen
Muneeb Ali, Aline Baggio
Gertjan Halkes, Tom Parker



VLSI Trends: Moore's Law

- in 1965, Gordon Moore **predicted** that transistors would continue to shrink, allowing:
  - **doubled** transistor density
  - **doubled** performance

  every 18-24 months

Gordon Moore
Intel Co-Founder

Bell's law: every decade a new generation



[Culler:2004]

Wireless Sensor Networks The beginning …

Next Century Challenges: Mobile Networking for "**Smart Dust**"

J. M. Kahn,
R. H. Katz,
K. S. J. Pister

(MobiCom 1999)

Smart Dust @ UC Berkeley

Advances in digital circuitry will bring us:

- ultra low-power devices, with
- small form factor, at
- very low cost

fostering a new range of applications

Autonomous sensing and communication in a cubic millimeter

Wireless sensor node

Integrated device

- power supply
- sensors
- embedded processor
- wireless link





Wireless sensor network

Many, cheap nodes

- wireless ⇒ easy to install
- intelligent ⇒ collaboration
- low-power ⇒ long lifetime



Envisioned applications

Urban warfare

Fire fighting



Medical

and many more…

Process industry

Agriculture

The first steps …

- Develop COTS hardware
- Develop software (TinyO
- Run experiments
- Prototype applications

[Vanderbilt, 2003]

[UCB, 2002]

[Princeton, 2004]

WSN research

Topics:

- self-configuration
- node localization
- low-bitrate communication
- ad-hoc routing
- in-network data processing
- time synchronization
- …



Constraints:

- robustness
- limited resources
- **energy efficiency**

Energy breakdown



TNOdes



The battery crisis (Moore's law evil twin brother)

Limited capacity

~2 kcal (per battery)

Slow increase of capacity

- ~8% yearly increase (Wh/cm^3)
- doubles every **9** years



Course information

- Goal:
  - to acquire knowledge and understanding of **Wireless Sensor Networks**, in particular, of how the inherent need for **energy-efficient operation** requires a new approach to distributed computing.
- Means:
  - by reading, presenting, and discussing **state-of-the-art** research papers

Course contents

- Lectures (2x)
  - wireless communication
  - ad-hoc + sensor networks
- Seminar (5x)
  - medium access control
  - localization
  - routing
  - data processing
  - prototyping & deployments

Seminar organization

- Audience
  - prepare by reading classic papers
  - submit short summary before class
- Presenters
  - select a special topic (**today**)
  - browse recent literature
  - propose paper for presentation (**-1 week**)
  - prepare Powerpoint slides (**-2 days**)
  - present paper + lead discussion





Wireless communication

- Error prone, unpredictable medium
- Impact on protocol stack
  - medium access control
  - localization
  - routing

Unrealistic assumptions in many WSN papers



Unit Disk Graph model

Bottom-up approach

- Wireless channel
  - RF propagation
  - noise & interference
- Physical layer
  - modulation
  - coding

Wireless = Waves

- Electromagnetic radiation
- Sinusoidal wave with a frequency/wavelength

$$f = \frac{c}{\lambda}$$

- Emitted by sinusoidal current running through a wire (transmitting antenna)
- Induces current in receiving antenna





Electromagnetic waves

- Propagation in vacuum



Electromagnetic waves

- Free-space loss
  - due to surface area increase

$$P_R = P_T G_T G_R \left(\frac{\lambda}{4\pi d} \right)^2$$

Also known as Friis free space formula



Antenna basics



0 dB_i 2.2 dB_i 14 dB_i

Antenna gain: $G = \frac{P_{directional}}{P_{isotropic}}$

dB and friends

- dB (Decibel)
  - Denote the **difference** between two power levels
  - (P2/P1)[dB] = 10 * $\log_{10}$ (P2/P1)
- dBm (dB milliWatt)
  - Denote the power level relative to 1 mW
  - P[dBm] = 10*$\log_{10}$(P/1mW)
- dBi (dB isotropic)
  - Denote the **gain** a given antenna has, as compared to a theoretical isotropic (point source) antenna

Antenna radiation in theory

Vertical Whip Antenna, 1/4 Wave







[http://www.rfcafe.com/references/electrical/antenna_patterns.htm]

Antenna radiation in practice



Distortion:
- metal objects
- electronics
- polarization



[http://www.mwrf.com/]

Wireless Transmission Impairments

- Attenuation (free space loss, directionality)
- Noise (thermal + impulse)
- Objects
  - **reflection** (+ scattering + diffraction)
  - absorption
  - refraction



Reflections ⇒ multipath distortion

- Propagation along multiple paths leads to self interference
- Unlike attenuation and noise, multipath cannot be handled by increasing the send power ☹





Reflections ⇒ shadowing



- A large object shields the area behind it
- As for multipath, shadowing cannot be handled by increasing the send power

Propagation loss

Attenuation =
path loss
+ shadowing
+ multipath

Fading depends
- location
- time
- frequency



[G. Janssen, ET4358]

Path-loss Exponents

$$P_R = P_T G_T G_R \left(\frac{\lambda}{4\pi d} \right)^2$$

- Depends on environment:
  - Free space 2
  - Urban area cellular 2.7 to 3.5
  - Shadowed urban cell 3 to 5
  - In building LOS 1.6 to 1.8
  - Obstructed in building 4 to 6
  - Obstructed in factories 2 to 3

Physical layer

- Encoding information as waves
  - modification of a **carrier** signal
  - high frequency: low loss, small antennas



- Modulation
  - digital to analog conversion (and back)
  - options: amplitude, frequency, phase

Digital modulation

- Amplitude Shift Keying (ASK):
  - very simple
  - low bandwidth requirements
  - very susceptible to interference
- Frequency Shift Keying (FSK):
  - needs larger bandwidth
- Phase Shift Keying (PSK):
  - more complex
  - robust against interference



Mote Evolution

Mote Type Year	WeC 1998	Rene 1999	Rene 2 2000	Dot 2000	Mica 2001	Mica2Dot 2002	Mica 2 2002	Telos 2004
Microcontroller								
Type	AT90LS8535		ATmega163		ATmega128			TI MSP430
Program memory (KB)	8		16		128			60
RAM (KB)	0.5		1		4			2
Active Power (mW)	15		15		8		33	3
Sleep Power (μW)	45		45		75		75	6
Wakeup Time (μs)	1000		36		180		180	6
Nonvolatile storage								
Chip	24LC256				AT45DB041B			ST M24M01S
Connection type	I^2C				SPI			I^2C
Size (KB)	32				512			128
Communication								
Radio	TR1000				TR1000	CC1000		CC2420
Data rate (kbps)	10				40	38.4		250
Modulation type	OOK				ASK	FSK		O-QPSK
Receive Power (mW)	9				12	29		38
Transmit Power at 0dBm (mW)	36				36	42		35
Power Consumption								
Minimum Operation (V)	2.7		2.7			2.7		1.8
Total Active Power (mW)	24				27	44	89	41
Programming and Sensor Interface								
Expansion	none	51-pin	51-pin	none	51-pin	19-pin	51-pin	10-pin
Communication	IEEE 1284 (programming) and RS232 (requires additional hardware)							USB
Integrated Sensors	no	no	no	yes	no	no	no	yes

Physical layer techniques

- Handling noise
  - channel coding
- Handling fading
  - location: antenna diversity
  - frequency: hopping, spread spectrum, OFDM, UWB
  - time: (retransmissions; link layer and up)

Channel coding

- **Forward** Error Correction (FEC)
  - add redundant information at sender
  - coding gain vs. overheads (code rate, processing)
- Types
  - block codes (BCH, Reed-Solomon)
  - convolution codes (Viterbi, Turbo)
- Error bursts
  - interleaving (at the expense of latency)

Radio Block Diagram



Radio interface

- Data
  - Serial Peripheral Interface (SPI) Bus



- Control
  - configuration (freq. channel, etc.)
  - TX/RX mode (**half duplex**)
  - power on/off (sleep modes)



Wireless Sensor Networks

- Technology push
  - "Smart Dust: autonomous sensing and communication in a cubic millimeter"
- Novel research area
  - focus on energy efficiency
- Hostile wireless environment
  - channel basics (RF propagation & interference)
  - physical layer (modulation & coding)

Home work

- Check out info on Blackboard
- Register with the CPM submission system
  - send {Name, student nr, NetID} to

    Koen Langendoen <k.g.langendoen@tudelft.nl>

  - try account at

    http://cpm.ewi.tudelft.nl/